


## Split Support Bracket

---

### Product information




This bracket is generally used for attaching the reinforcement spine and used in conjunction with the adjustable suspension bracket for variable height configurations.

... [Read more](#)

---

## Split Support Bracket

### Blueprint



### Technical data

Part code	Profile No.	Support bracket No.	B mm	H, mm	L mm	h mm mm	s mm mm	e mm mm	D, mm	l mm mm
600523B03	23,000	23.B03	48	78	50	60	4	8	M12	-
600524B03	24,000	24.B03	57	88	50	70	4	8	M12	-
600525B03	25,000	25.B03	77	131	90	94	6	10	M16	-
600526B03	26,000	26.B03	96	150	110	112	8	10	M16	-
600527B03	27,000	27.B03	110	180	120	148	10	15	M16	80